



SNAPTIGHT
PRODUCTS
★ INSULATED BUILDING PRODUCTS ★

PICTURE WINDOW TRIM PACK INSTALLATION GUIDE

SnapTight Products Window Trim Packs are designed for easy installation. They are pre-cut to the sizes needed for standard window sizes 2x3, 3x3, 3x4, and 4x4, so there is no need to alter the products before installation if your window size is as listed, outside of jam pieces when needed. There are two processes for installation based on your windows leveling to the wall. A window that is sunken into the wall will require jam pieces, which can be provided at additional cost to the standard packs.

Materials Needed

- Loctite 3X Adhesive (provided)
- Metal Cleats (provided)
 - Measuring Tape
 - Electric Drill
 - Screws
- Chalk Line or Marking Utensil
- Color Match Caulk (can be provided at additional cost)

IF JAM PIECES ARE NEEDED

For a window that is sunken into the wall, the jam pieces are installed first.

Apply adhesive to the backs of the jam pieces, being careful not to over apply to avoid adhesive being pushed out of the sides and install to the portions of wall that extends past your window.

These pieces will be sideways, facing each other, while the trim pieces will face out. Apply pressure to the length of the product to spread the adhesive and close gaps.

Place screws into the corners to keep products in place while adhesive cures. Now you can install the trim pieces by following the flush guide.

INSTALLING WINDOW TRIM

For a window flush with the wall, you will need to measure the distance needed from the window frame to the groove on the backs of the products. We recommend using a chalk line for ease.

These grooves will be snapped onto the cleats provided with the product. When you have your distances marked onto your wall and have checked its accuracy, install the cleats with screws to the mark or line measured to ensure that the cleats will line up properly with the grooves on the back of the products to achieve a proper and flush finish.

Then apply adhesive provided with the products onto the back of the window trim piece, and then onto the cleats now installed onto your wall. Be careful not to overapply adhesive to avoid it getting pushed out of the sides of the trim.

Ensure when you are installing the pieces that they are exactly where they are measured to be so the finished product will be seamless and aligned. Snap the trim piece with adhesive applied onto the cleats with adhesive applied with the groove on the back of the product.

Apply pressure through the length of the trim to spread the adhesive and close gaps. Screw to wall with washers and screws while adhesive cures.

Repeat with the remaining trim pieces, but now with applying adhesive to the ends of the pieces already installed that are to come together.

When the adhesive is cured, remove all washers and screws. The last step is to use a color matched caulk and seal ALL the windows edges, both to the wall and window frame, and to the other pieces of the product. Apply an even and necessary amount based on the space of the edge, and using your finger or a tool, press the caulk into the edges and connecting corners and smooth out. Then fill the screw holes with same caulk and smooth out. Allow the caulk to dry, and your window trim is installed!

THANK YOU FOR CHOOSING SNAPTIGHTPRODUCTS!



www.SNAPTIGHTPRODUCTS.com