





Address Plaques Installation Manual

SnapTight Products exterior stucco address plaques are simple and easy to install to any residential and commercial building, old or new and on any surface.

SnapTight Products exterior stucco address plaques are made of durable weather-resistant material from expanded polystyrene (EPS) foam, coated in polyurea and stucco for durability, then painted any color you need, making them a decorative and lightweight accessory that is impervious to the elements.

MATERIALS NEEDED

- Your Exterior Stucco Address Plague.
- The Address Numbers You Choose To Use.
- Construction Adhesive, We Recommend Using Loctite 3x Grab Adhesive.
 - A Brace, Tape, Or 2 Screws
 - A Level
- 1. Attach your address numbers that you choose to use as per the install instructions directed on them.
- 2. Apply Loctite 3x Grab Adhesive Construction Adhesive To The Back Of The Address Plaque.
- 3. Press The Address Plaque To The Building, use level to make sure the plague is leveled.
- 4. Use A Brace, Tape Or 2 Screws To Hold The Stucco Address Plague In Place Until The Loctite 3x Grab Adhesive Construction Adhesive Dries, About 24 Hours.
- 5. After 24 hours and the Loctite 3x Grab Adhesive construction adhesive is dry, remove the brace, tape, or the 2 screws that were used to hold the plaque in place.

You now have installed a maintenance free durable decorative address plague. ENJOY!

Do you have any questions about this product? Would you like to learn more about our other products?

Reach out to our team today!

208.252.7285 www.snaptightproducts.com snaptightproducts@gmail.com

Facebook @snaptightproducts Instagram snaptightproducts YouTube SnapTight Products







